

## **Safe Work Practice**

Name of Job: Control Of Traffic Flow On		Development Date: March 14th, 2011		Developed By: CSNS
Work Sites				
Possible Hazards Present				
Environment	Falling objects		Slips trips and	falls Moving vehicles
	(1800) 1800 (18 - 5000) 1800 (1800) 1800 (	90   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   191   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001   2001	900 (	antenna anti anti anti anti anti anti anti a
Personal Protective Equipment (PPE) and Devices Recommended				
Reflective Vest	Head p	**************************************	Eye Protection	ant and
Foot Protection	/ 1888 / 1888 / 18 <sup>-1 -</sup> 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888 - 1888			

## What are some good general safe work practices?

- **DO** erect signs and barricades to direct traffic safely around worksite.
- DO restrict on site traffic.
- **DO** obtain authorization to enter restricted work areas, leases or plant sites.
- **DO** ensure that Vehicles should park pointed towards the exit with the doors closed, unlocked and the keys in the ignition.
- **DO** ensure that prior to operation, the operator must perform a walk around check of the vehicle.
- **DO** operate vehicles in a safe, courteous manner.

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.