



35 MacDonald Ave,  
 Dartmouth, NS, B3B 1C6  
 Tel: 902 468 6696  
 Toll Free NS: 1 800 971 3888  
 Web: [www.constructionsafetyns.ca](http://www.constructionsafetyns.ca)

## SAFE WORK PRACTICE

Name of Job: <b>Crushing Operations</b>	Development Date:	Developed By:	Approved By:	Review Date:
--	-------------------	---------------	--------------	--------------

### Possible Hazards Present

Contact with machinery	Working in extreme temperatures and UV radiation.	Working with hand tools, powered tools and heavy powered equipment	Risk of eye injury from flying particles.
Respiratory hazards from rock dust.			

### Personal Protective Equipment (PPE) and Devices Recommended

Hearing Protection	Eye Protection	Foot protection	Fall Arrest Equipment
Respirator Equipment	Skin Protection	Hearing Protection	

**What are some good general safe work practices?**

- **DO** Ensure that all workers are conversant with worksite operations that are part of a crushing operation.
- **DO** ensure that operators are familiar with the lock out system.
- **DO NOT** attempt to rectify any electrical and/or hydraulic problems without first “locking out” the equipment.
- **DO NOT** cross, jump or touch any moving conveyer.
- **DO** ensure the use of ladders and the provided access and exit points from all crushing equipment.
- **DO** ensure that Loader operators maintain good housekeeping practices.

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at [constructionsafetyns.ca](http://constructionsafetyns.ca) or 1.800.971.3888.

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at [constructionsafetyns.ca](http://constructionsafetyns.ca) or 1.800.971.3888.