

35 MacDonald Ave, Dartmouth, NS, B3B 1C6 Tel: 902 468 6696

Toll Free NS: 1 800 971 3888 Web: www.constructionsafetyns.ca

SAFE WORK PRACTICE

Name of Job:	Development Date:	Developed By:	Approved By:	Review Date:
Lockout Of				
Pressure Systems				

Possible Hazards Present

Use of various machinery and tools.	Exposure to toxic chemicals or materials.	Working in extreme temperatures and UV radiation.	Working with hand tools, powered tools and heavy powered equipment
Release of			
compressed gas or liquid			

Personal Protective Equipment (PPE) and Devices Recommended

Hearing Protection	Eye Protection	Foot protection	Fall Arrest Equipment
Respirator Equipment	Skin Protection	Hearing Protection	

What are some good general safe work practices?

- **DO** isolate system according to safe job procedure.
- **DO** Depressurize and drain system.
- **DO** purge the system if combustible materials or hazardous gas, vapor, dust or fumes exist.
- DO isolate all lines tying into the system.
- **DO** install locking devices and tags on all valves that would affect the system if operated.
- **DO** continually monitor the area for combustible material and hazardous gases.
- DO Remove Lock Out Devices.
- Note: Lock out devices can only be removed by the persons that installed them.

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.

