

Safe Job Procedures

Name of Job:	Developme	ent Date:	Developed By:
Band saw	March 30th	ı, 2011	CSNS
Possible Hazards Present			
Exposed blades - cuts, E amputations	entrical shock	Excessive noise	Saw dust in eyes
Inhalation of saw dust particles	(1 mar) haar) kaar) kaar	का राज्य राज्य राज्य हैं की बाद की	14 (40
Personal Protective Equipment (PPE) and Devices Recommended			
Safety glasses	onenenenenenenenenenenenenenenenenenene	Steel toed boots	Hearing protection
[2001 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1 1000 1	(† 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1800 † 1	900 1000 1000 1005 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 	t (mit mit mit mit mit mit mit mit mit mit

What is a proper safe job procedure to follow?

- Ensure saw is unplugged or locked out
- Inspect work area to ensure clean
- Inspect electrical cords, switches, blade and guards for defects (all defective items will be tagged out of service)
- Inspect wood to ensure there are no defects or nails/screws in wood
- Place wood on work platform and measure height of wood
- Adjust guard to 1/8 inch above the height of wood
- Turn on saw and inspect blade as it runs to ensure no defects
- Push wood through saw and wait until blade stops to remove wood from platform
- Use a push stick if wood is small
- Unplug or lock
- If there is a lot of saw dust, wear a dust mask while cleaning

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.