

Safe Job Procedures

Name of Job:		Development Date:			Developed By:	
Fuelling Vehicles		March 30th, 2011			CSNS	
Possible Hazards Present						
Eye injury Fire/E		xplosion Skin exposure		2 (1002 (1002 (1002 (1002 (1002 (1000 (Inhalation of hazardous vapors	
Burns	1 900 1 18 d ^{e s} eme 1 900 1 900 1 900 1 900 1 900 1 900 1) 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800	rmirmirk (m	900 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000	9 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1110 (1	•
Personal	Protectiv	e Equipmei	nt (P	PPE) and Device	es Reco	ommended
Steel toed boots Eye pro		otection Hand protection		1 (m) (m) (m) (m) (m) (m) 9 n 9 (m) (m) (m) (m) (m) (m) (m)	pang mang mang mang mang mang mang mang m	
Sent - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	11111111111111111111111111111111111111		97.0		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	n .

What is a proper safe job procedure to follow?

- Bring the vehicle to pump ensure the side of the vehicle with tank access is closest to the pump
- Shut off ignition, extinguish any smoking material, leave cell phone in vehicle
- Remove fill cap
- Insert nozzle in to tank and flip pump lever to the "on" position
- Fill until desired quantity is obtained or until click is heard to indicate a full tank and then turn lever to the "off" position
- Place nozzle back on holder and replace the fill cap
- Wash any excess material off of hands promptly

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.