

Safe Job Procedures

Name of Job:		Development Date:		Developed By:	
Greasing a Vehicle	March	March 30th, 2011		CSNS	
	Possih	le Hazards Preser	nt		
1 OSSIDIE Hazarus I Tesent					
Eye injury	Crush injuries	Burns		Potential death	
Exposure to chemical	14 () 		man e ma E man e		
Personal Protective Equipment (PPE) and Devices Recommended					
Steel toed boots	Eye protection	Hand prote	ection		
/-	/-			,	

What is a proper safe job procedure to follow?

- Shut off machine and utilize lock out procedure, including tagging and chocking the equipment
- Lay on creeper with grease gun, towel and roll under vehicle
- Clean each grease fitting and apply grease
- Check for fittings that need to be replaced
- Clean grease gun thoroughly when finished and put all tools used away
- Remove wheel chocks and lock out tags

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.