

Safe Job Procedures

Name of Job:	Developmen		Developed I	Зу:
Supporting (Chocking) March 30th	, 2011	CSNS	
Dump Boxes				
Possible Hazards Present				
genanananananananananananananananananana	miniminiminiminiminiminiminiminiminimin	Potential death	(1 ma (ma (ma (ma (ma (ma)) mu) mu) mu) mu)	maner e L
Serious injury	Pinch points	Potentiai death		
Peruncipun suuri suur	2001 2001 2002 2003 2003 2003 2003 2004 2004 2004 2004 2004 2004 2004 2004 2004) mar mar mar mar mar mar ¹ 1 mar mar mar mar mar	omer mar mar mar mar mar mar mar mar mar ma
Querran es merma es mar esmerma es mar es "mar es " "mar	2001 2001 2001 2001 2001 2001 2001 2001 2001 2001 2001 2001 2001 2001 2001 2001	. 2007 25 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000) 1000 1000	omer mar mar mar mar mar mar mar mar mar ma
Personal Protective Equipment (PPE) and Devices Recommended				
ya ina ina ina ina ina ina ina ina ina in	1801 1801 1802 1801 1801 1801 1801 1801 1801 1801 1801 1801 1801 1801 1801 1801	· · · · · · · · · · · · · · · · · · ·) 1001 1001 1001 1001 1001 1001 ; juni 1001 1001 1001 1001	man
Eye protection	Steel toed boots	Hand protectio	n [Har	d hat
The contract	1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800 1800		e ma e ma e ma e ma e ma e ma e for ma e ma e ma e ma e ma e	amar mari mari mani mani mani mani mani mani mani man
F. General construction and construction and construction and construction and construction and construction of t			:	;/ ;/

What is a proper safe job procedure to follow?

- Park and block truck in neutral with the power take off (PTO) and pump engaged
- Raise truck box to desired level
- A Stiff Leg is a permanently attached pivot and rest, and is the preferred method of support
- If not available, use the following:
 - 6"x 6"x 6" long timber block across the truck frame between the box and subframe as close as possible to the box hinge
 - 2 pieces of 4"x 4"x 6" timber placed vertically between tandem tire and the box
 - Pin locks provided by the manufacturer to secure the box in the elevated position
- Only keep the box lifted for as long as required

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.