

Safe Job Procedure for Bench Grinders

Pre Set-Up and Use of Grinder

- Ensure lighting is adequate.
- Do not wear loose clothing.
- Make sure there are no flammables around grinder
- Make sure the stone guard is set at proper angle to protect your eyes.
- Make sure the stone is no more than 1.55 mm to inside edge of rest.
- Make sure you're wearing appropriate PPE.
- Make sure grinding stone is in good condition.

To replace a damaged grinding stone

- Review and follow specific manufacturer's instructions.
- Unplug grinder from wall.
- Make sure rotation has stopped, push and hold lock pin to hold stone.
- Use appropriate wrench to loosen and remove arbour lock bolt.
- Replace stone with proper grade and size.
- Make sure nut is faced the right way depending on the application stone.
- Screw on the nut and tighten it firmly with the matching wrench.
- Remove finger from lock pin.
- Plug back into wall

Operation Procedure

- 1. Start the grinder by pressing the switch to on.
- 2. Firmly push the work piece down on the rest and slowly apply it to the stone.
- 3. Be prepared to have sparks.
- 4. While grinding, do not lift work piece off the rest. It will cause the work piece to catch the stone and possibly cause injury.
- 5. Try and keep the work piece 90 degrees to the grinding stone or it might catch and pull it from your hands.
- 6. Remove work piece from rest first pulling it away from stone.
- 7. Turn off Grinder and do not leave grinder till it stops rotating.
- 8. Keep the work area clean for other people to use it.



35 MacDonald Ave, Dartmouth, NS, B3B 1C6 Tel: 902 468 6696 Toll Free NS: 1 800 971 3888

Fax: 902 468 8843

Web: www.constructionsafetyns.ca

Additional Considerations

- Grinding produces heat so gloves are recommended, however, gloves should be snug fitted to avoid catching in moving equipment.
- Always make sure the saw is unplugged before changing the stone.
- Consult the supervisor if unsure of how to use.