

35 MacDonald Ave, Dartmouth, NS, B3B 1C6 Tel: 902 468 6696 Toll Free NS: 1 800 971 3888

Fax: 902 468 8843

Web: www.constructionsafetyns.ca

Safe Job Procedure for Driving (Motor Vehicles)

Pre-operation check and adjustments

- Conduct a "circle check" inspection of your vehicle.
- Maintenance staff who operate District vehicles are required to conduct and document vehicle inspections at designated time intervals.
- Look inside your vehicle before you unlock the door and get in.
- Clear ice and snow from your vehicle.
- Remove items from your pants pockets; they could press on soft tissue and reduce circulation.
- Position items that you may need during driving (e.g. sunglasses) in an easy to reach location.
- When seated, scoot your tail bone as far back in the seat as possible.
- Adjust your mirrors so they can be used without straining your neck or
- upper body.
- Adjust the lumbar support so the lower part of your back is supported with no pressure points or gaps. A small rolled-up towel can also be used in the curve of your lower back.
- Adjust the seat back tilt so it fully supports your back. The least amount of pressure
 occurs when the seat back is slightly reclined. The backrest should provide continuous
 support along the length of the back.
- Adjust the **seat pan tilt** so your knees are slightly lower than your hips.
- This opens up your hip flexors and increases circulation to the back.
- Your thighs should be supported along the length of the cushion.
- Adjust the seat depth and/or the steering wheel so you are able to drive with your shoulder relaxed and your arms close to your sides.
- Ensure you can fully depress the pedals and see the display panel.
- Adjust the seat height so you have maximum vision of the road and adequate head clearance from the roof.
- Adjust the **head rest/restraint** so it is level with the top of your head.
- Buckle up before driving. If the seat belt strap is uncomfortable then use a piece of soft foam or cushion on the strap.
- Warm up your vehicle; it reduces condensation on the windows.
- · Check oil and fuel levels.



35 MacDonald Ave, Dartmouth, NS, B3B 1C6 Tel: 902 468 6696 Toll Free NS: 1 800 971 3888

Fax: 902 468 8843

Web: www.constructionsafetyns.ca

1. Operating the vehicle

- Keep your two hands on the steering wheel except when shifting gears.
- Change your hand postures frequently to improve circulation and reduce fatigue.
- Position your hands at "10 and 2 o'clock" on the steering wheel.
- Keep your eyes moving and watch the entire traffic environment.
- Use rear view and side mirrors often.
- Adjust your driving to the road and weather conditions.
- Keep the windshield and windows clear.

2. Refueling

- Shut off the engine.
- Do not smoke or use a cell phone while refueling.
- Remove the fuel cap slowly, holding it at the semi-locked position until pressure is released.
- Allow the nozzle to completely empty before removing it.

3. Parking

- Park in a visible, well-lighted area wherever possible.
- Only park in designated parking spaces.
- Always back your vehicle into a parking stall/space.
- Utilize a two person backup system whenever a second staff member is available. The
 driver must be able to see the spotter at all times while assisting to safely backup the
 vehicle.
- Put up your windows and lock the doors.
- Do not leave valuables in your vehicle.