

Safe Job Procedures

Name of Job:	Developmen		Developed By:
Pumping Water	March 30th,	2011	CSNS
Possible Hazards Present			
1 OSSIDIE HAZAI US I LESENT			
Slips, trips and falls	Tool damage		
gad 1 mai 1 mai E E E	(2001 2		
Personal Protective Equipment (PPE) and Devices Recommended			
		900 (e mar
Steel toed boots	Hand protection	Eye protection	1
	gun e san e		emet mit mit emit mit mit mit mit mit mit mit mit mit
		2, 402, 402, 402, 402, 402, 402, 402, 40	

What is a proper safe job procedure to follow?

- Place pump on level ground
- String out hoses for discharge make sure all bends and knots are out
- Connect hose to pump and attach suction make sure the end of the hose is in deep water
- Service and prime the pump
- Use cold start procedure and run the pump (do not run the pump when it is empty)
- Check on pump periodically to ensure it is not plugged or running out of water
- After job is finished, roll up discharge hose, making sure it is completely empty
- Remove suction line and put all hoses on to truck empty pump of water and load
- Make sure load is secure

Please note: This document is for information purposes only as a guide. The safe job procedures (SJP) and safe work practices (SWP) created for your workplace should reflect your organizations processes, equipment and hazards as identified by a hazard analysis. Construction Safety Nova Scotia does not assume responsibility for the use of information in this document. If assistance is needed to complete a SWP and SJP for your organization please contact CSNS member services at constructionsafetyns.ca or 1.800.971.3888.